



Roll 3" glass tape over the stern by 1"-2" to protect stern panel from water and wear!

Trim tape to match chine seam and bevel (sand) tape edge to match side panel angle

Use a 2-3" putty knife to fair in the edges. 3/4" wide is good enough for the 3" tape and 4oz cloth

Fairing compound used on the outside hull seams and the fiberglass tape and cloth finished edges

Fair edges of glass tape and along the edge of the fiberglass cloth

Use knife to cut along upper edge of masking tape

2"-3" overlap of the chine seams

For a first time builder or to keep it simple, a 2"-3" overlap of the chine seams on the bottom is enough to protect the hull